



Telefonos compatibles con fecha 07/06/2010

NOKIA

Nokia 2323 classic, Nokia 2330 classic, Nokia 2600 classic, Nokia 2630, Nokia 2660, Nokia 2680 slide, Nokia 2690, Nokia 2700 classic, Nokia 2710 Navigation Edition, Nokia 2720 fold, Nokia 2730 classic, Nokia 2760, Nokia 2865, Nokia 2865i, Nokia 3109 classic, Nokia 3110 classic, Nokia 3110 Evolve, Nokia 3120 classic, Nokia 3208 classic, Nokia 3230, Nokia 3250, Nokia 3500 classic, Nokia 3555, Nokia 3600 slide, Nokia 3710 fold, Nokia 3720 classic, Nokia 5000, Nokia 5130 XpressMusic, Nokia 5200, Nokia 5220 XpressMusic, Nokia 5230, Nokia 5230 Nuron, Nokia 5235 Comes With Music Edition, Nokia 5300 XpressMusic, Nokia 5310 XpressMusic, Nokia 5320 XpressMusic, Nokia 5330 Mobile TV Edition, Nokia 5500 Sport, Nokia 5530 XpressMusic, Nokia 5610 XpressMusic, Nokia 5630 XpressMusic, Nokia 5700 XpressMusic, Nokia 5730 XpressMusic, Nokia 5800 XpressMusic, Nokia 6021, Nokia 6085, Nokia 6086, Nokia 6102i, Nokia 6103, Nokia 6110 Navigator, Nokia 6111, Nokia 6120 classic, Nokia 6121 classic, Nokia 6124 classic, Nokia 6125, Nokia 6126, Nokia 6131, Nokia 6131 NFC, Nokia 6133, Nokia 6136, Nokia 6151, Nokia 6208 classic, Nokia 6210 Navigator, Nokia 6212 classic, Nokia 6220 classic, Nokia 6230, Nokia 6230i, Nokia 6233, Nokia 6234, Nokia 6255, Nokia 6260, Nokia 6260 slide, Nokia 6263, Nokia 6265, Nokia 6265i, Nokia 6267, Nokia 6270, Nokia 6275, Nokia 6275i, Nokia 6280, Nokia 6282, Nokia 6288, Nokia 6290, Nokia 6300, Nokia 6300i, Nokia 6301, Nokia 6303 classic, Nokia 6303i classic, Nokia 6350, Nokia 6500 classic, Nokia 6500 slide, Nokia 6600, Nokia 6600 fold, Nokia 6600 slide, Nokia 6600i slide, Nokia 6620, Nokia 6630, Nokia 6650 fold, Nokia 6670, Nokia 6680, Nokia 6681, Nokia 6682, Nokia 6700 classic, Nokia 6700 slide, Nokia 6710 Navigator, Nokia 6720 classic, Nokia 6730 classic, Nokia 6750 Mural, Nokia 6760 slide, Nokia 6788, Nokia 6788i, Nokia 6790 slide, Nokia 6790 Surge, Nokia 7020, Nokia 7100 Supernova, Nokia 7210 Supernova, Nokia 7230, Nokia 7310 Supernova, Nokia 7370, Nokia 7373, Nokia 7390, Nokia 7500 Prism, Nokia 7510 Supernova, Nokia 7610, Nokia 7610 Supernova, Nokia 7710, Nokia 7900 Prism, Nokia 8600 Luna, Nokia 8800, Nokia 8800 Arte, Nokia 8800 Carbon Arte, Nokia 8800 Gold Arte, Nokia 8800 Sirocco Edition, Nokia 8801, Nokia 9300, Nokia 9500, Nokia C3-00, Nokia C5-00, Nokia C6-00, Nokia E5-00, Nokia E50, Nokia E51, Nokia E52, Nokia E55, Nokia E60, Nokia E61, Nokia E61i, Nokia E62, Nokia E63, Nokia E65, Nokia E66, Nokia E70, Nokia E71, Nokia E71x, Nokia E72, Nokia E75, Nokia E90 Communicator, Nokia N70, Nokia N71, Nokia N72, Nokia N73, Nokia N75, Nokia N76, Nokia N77, Nokia

N78,Nokia N79,Nokia N8,Nokia N80,Nokia N81,Nokia N81 8GB,Nokia N82,Nokia N85,Nokia N86 8MP,Nokia N90,Nokia N91,Nokia N91 8GB,Nokia N92,Nokia N93,Nokia N93i,Nokia N95,Nokia N95 8GB,Nokia N95-3 NAM,Nokia N96,Nokia N96-3,Nokia N97,Nokia N97 mini,Nokia X2-00,Nokia X3-00,Nokia X6-00.

SONY

Aino,Ainoa,C510,C510a,C510c,C702,C702a,C702c,C901,C901aGreenheart,C901Greenheart,C902,C902c,C903,C903a,C905,C905a,C905c,ElmJ10,ElmJ10i2,G502,G700,G700c,G705,G705a,G705u,G900,HazelJ20,HazelJ20i,Jalou,K320i,K510a,K510c,K510i,K530c,K530i,K550c,K550i,K550im,K600i,K608i,K610,K610i,K618i,K630i,K660i,K770i,K790a,K790c,K790i,K800i,K810i,K818c,K850i,K858c,M600i,M608c,Naite,Naitea,P1c,P1i,P900,P908,P910,P910a,P910c,P990i,S500c,S500i,Satio,Satioa,T650i,T658c,T700,T707,T707a,T715,T715a,TM506,V600,V640,VivazProU8a,VivazProU8i,VivazU5a,VivazU5i,W300c,W300i,W508,W508a,W518a,W550c,W550i,W580c,W580i,W595,W595a,W595c,W600c,W600i,W610c,W610i,W660i,W700c,W700i,W705,W705u,W710c,W710i,W715,W760c,W760i,W800c,W800i,W810c,W810i,W830c,W830i,W850i,W880i,W888c,W890i,W900c,W900i,W902,W908c,W910i,W950i,W958c,W960i,W980,W995,W995a,Yari,Yaria,Z520a,Z520c,Z520i,Z525a,Z525i,Z530c,Z530i,Z550i,Z558,Z610,Z610i,Z710,Z710c,Z710i,Z750,Z770,Z780.

MOTOROLA

A1000,A780,A845,A910,AURA,E1000,E1070,E770,i580,i605,i615,i870,i875,i876,i880,ic902,L6,L6i,M1000,MOTO Q11,MOTO U9,MOTO VE66,MOTO Z10,MOTO Z6w,MOTO Z8,MOTO Z9/Z9n,MOTOACTV W6,MOTOKRZR K1,MOTOKRZR K3,MOTOMING A1200,MOTOMING A1600,MOTOPEBL U3,MOTOPEBL U6,MOTORAZR maxx V6,MOTORAZR V3 (CLDC 1.1),MOTORAZR V3i,MOTORAZR V3t,MOTORAZR V3x,MOTORAZR V3xx,MOTORAZR VE20,MOTORAZR2 V9,MOTORAZR2 V9x,MOTORIZR Z3,MOTOROKR E2,MOTOROKR E6/E6e,MOTOROKR E8,MOTOROKR EM30,MOTOSLVR L7,MOTOSLVR L7i/L7e,MOTOSLVR L9/L72,ROKR EM35,T280i,V1100,V197,V360,V400,V500,V550,V551,V600,V620,V635,V80,V950,VE538,W490,W510,W760r/VA76r.

SAMSUNG

GT-B2700,GT-I8510,GT-I8910,GT-M8800,GT-S3650,GT-S5230,GT-

S5320,GT-S5600,GT-S8000,i300,i320,i8510 INNOV8,I907 Epix,Instintic M800,SGH A167,SGH A177,SGH A257,SGH A657,SGH A827,SGH A887,SGH D720,SGH G800,SGH I600,SGH I627,SGH I710,SGH I780,SGH I900,SGH T719,SGH-A867,SGH-D830,SGH-D840,SGH-D900,SGH-D908,SGH-E200,SGH-E258,SGH-E380,SGH-E388,SGH-E390,SGH-E740,SGH-E780,SGH-E788,SGH-E810,SGH-E898,SGH-E950,SGH-F330,SGH-F400,SGH-F480,SGH-F500,SGH-G400,SGH-G600,SGH-G810,SGH-i450,SGH-i550,SGH-i560,SGH-J600,SGH-L600,SGH-M610,SGH-P260,SGH-P520,SGH-T729,SGH-U600,SGH-U700,SGH-U800,SGH-U900,SGH-X820,SGH-Z720.

SIEMENS

C81,CF61,CX75,E71,E81,EF81,EF91,EL71,M75,M81,S65,S66,S75,S81,SK65,SL75,SL80,SL91,SP65,SX1,SXG75.

LG

BL20,BL40,CB630,CF360,CT810,CU720,GD580,GD710,GM630,GM730,GM750,GR500,GT500,GT505,GT810H,GW820,HB620/KB620,HB620T,KB770,KB775,KC910,KC910E,KC910I,KC910Q,KC910QA,KE500,KE800,KF310/KF311,KF690,KF700,KF701,KF750,KF755,KF757,KG195,KS10,KS500,KT520,KT525,KT610,KU990
Viewty,KU990I,LG280,LG830,LX265,LX280,LX290,LX370,LX400,LX570/LG570,LX600,LX610,SH150,U370,U730,Wave (AX-380).

BLACKBERRY

BlackBerry 7130,BlackBerry 7130c,BlackBerry 7130e (Version 4.2.1 o superior),BlackBerry 7130g,BlackBerry 8700,BlackBerry 8700c (Version 4.2.1 o superior),BlackBerry 8700g (Version 4.2.1 o superior),BlackBerry 8700r (Version 4.2.1 o superior),BlackBerry 8703e,BlackBerry 8707,BlackBerry 8707g,BlackBerry 8707h,BlackBerry 8800,BlackBerry 8820,BlackBerry 8830,BlackBerry Bold 9000,Blackberry Bold 9700,BlackBerry Curve 8300,BlackBerry Curve 8310,BlackBerry Curve 8320,BlackBerry Curve 8330,BlackBerry Curve 8350i,Blackberry Curve 8520,Blackberry Curve 8530,BlackBerry Curve 8900,BlackBerry Pearl 8100 (Version 4.2.1 o superior),BlackBerry Pearl 8110,BlackBerry Pearl 8120,BlackBerry Pearl 8130,BlackBerry Pearl 8220,Blackberry Pearl 8230,BlackBerry Storm 9500,BlackBerry Storm 9530,Blackberry Storm2 9520,Blackberry Storm2

9550,Blackberry Tour 9600,Blackberry Tour 9630.

PDA

Cualquier PDA con sistema Windows Mobile 2003, 2005 y 2006 es compatible con el sistema BlueKey para PocketPC

Coltec S.L. no se compromete a compatibilidad con ningún modelo ya que el fabricante puede cambiar las características de sus teléfonos.